

<p>ASTRA 99/02 ZAFIRA</p>  <p><b>08473</b> MOV-273</p>	<p>ASTRA 03/</p>  <p><b>04113</b> MOV-274</p>	<p>CELTA 00/06 C/REFORCO</p>  <p><b>12723</b> MOV-270</p>	<p>CORSA 94/99</p>  <p><b>14746</b> MOV-256</p>	<p>CORSA 03/</p>  <p><b>15235</b> MOV-266</p>
<p>FOX 04/09</p>  <p><b>04112</b> MOV-845</p>	<p>FOX / SPACEFOX 10/</p>  <p><b>04116</b> MOV-776</p>	<p>GOL 87/94</p>  <p><b>14744</b> MOV-883</p>	<p>GOL 95/99</p>  <p><b>14750</b> MOV-782</p>	<p>GOL 08/ GV</p>  <p><b>04114</b> MOV-800</p>
<p>GOLF 99/07</p>  <p><b>14171</b> CR-10297</p>	<p>KADETT 96/98</p>  <p><b>08471</b> MOV-272</p>	<p>PASSAT 86/</p>  <p><b>08474</b> PLAS-575</p>	<p>SANTANA 87/90</p>  <p><b>08465</b> MOV-376 <b>04209</b> 6190</p>	<p>SANTANA/VERSAILLES 91/98</p>  <p><b>04369</b> MOV-372</p>
<p>SANTANA 99/</p>  <p><b>08468</b> MOV-377</p>	<p>UNO 10/</p>  <p><b>04345</b> 3500</p>	<p>VECTRA 97/05</p>  <p><b>09058</b> MOV-267</p>		

<p>CORSA 94/99</p>  <p><b>08469</b> MOV-258</p>	<p>CORSA SEDAN 96/02</p>  <p><b>04070</b> MOV-259 <b>08470</b> PLAS-1984</p>	<p>GOL 87/94</p>  <p><b>14745</b> MOV-899</p>	<p>GOL 95/99</p>  <p><b>04115</b> MOV-783</p>	<p>GOL 99/ GIII</p>  <p><b>09234</b> 6411</p>
<p>GOL 08/ GV</p>  <p><b>08466</b> MOV-837</p>	<p>KADETT 96/98</p>  <p><b>08472</b> PLAS-1988</p>	<p>PARATI 95/99</p>  <p><b>04711</b> MOV-780</p>	<p>PASSAT 86/</p>  <p><b>08475</b> PLAS-576</p>	

<p>F1000 93/96 TRASEIRO LATERAL</p>  <p><b>07832</b> MP-51265</p>	<p>F1000 93/96 TRASEIRO SUPERIOR CENTRAL</p>  <p><b>07842</b> MP-51622</p>	<p>F1000 93/96 SUPERIOR</p>  <p><b>07840</b> MP-51620 LD <b>07841</b> MP-51621 LE</p>		
--	---	--	--	---









































<p><b>14112</b> GB-8004 BRASILIA  <b>03012</b> GB-8012 CHEVETTE /86  <b>14100</b> SA-1053 FUSCA / BRASILIA  <b>04001</b> GB-8014 FUSCA/BRASILIA ORIGINAL  <b>03013</b> GB-8003 GOL /86 FINO  <b>14064</b> GB-8010 GOL /86 LARGO C/CINTA  <b>04765</b> GB-8002 PASSAT</p>				<p>UNIVERSAL BATENTE TIPO HONDA PRETO 2 PEÇAS</p> <p><b>18477</b> SA-3004</p>			
<p>D20</p> <p><b>09299</b> 2059G DIANT/TRAS 4 PEÇAS  <b>14066</b> GB-8035 DIAANTEIRO  <b>14067</b> GB-8036 TRASEIRO</p>		<p>F1000 /92 DIAANTEIRO</p> <p><b>14065</b> GB-8040</p>		<p>OPALA 85/87 COMODORO</p> <p><b>09303</b> 1132G DIANT LD/LE  <b>08315</b> 1133G TRAS</p>		<p>UNIVERSAL PRETO 400MM 2 PEÇAS</p> <p><b>18478</b> SA-3006</p>	
<p>OPALA 85/87 DIPLOMATA</p> <p><b>09301</b> 971G DIANT PRETO/CROM LD  <b>09302</b> 972G DIANT PRETO/CROM LE  <b>09300</b> 970G/3093G TRAS PRETO/CROMADO</p>		<p>GARRA PARACHOQUE CORCEL II L</p> <p><b>09451</b> G-444 DIAANTEIRO LD  <b>09452</b> G-445 DIAANTEIRO LE  <b>09453</b> G-446 TRASEIRO LD/LE</p>		<p>UNIVERSAL PRETO 600MM 2 PEÇAS</p> <p><b>18479</b> SA-3008</p>			

<p>DIAANTEIRO DEL REY</p> <p><b>06495</b> J-40475</p>		<p>DIAANTEIRO ESCORT 84/86</p> <p><b>07800</b> G-430 LD  <b>07801</b> G-431 LE</p>		<p>TRASEIRO DEL REY</p> <p><b>06496</b> J-40476</p>		<p>TRASEIRO ESCORT 84/86</p> <p><b>07799</b> G-429</p>			
<p>DIAANTEIRO PEUGEOT 206 99/03</p> <p><b>16499</b> RBP-3005</p>		<p>DIAANTEIRO PEUGEOT 206 04/08</p> <p><b>19248</b> 10.PG.0295</p>		<p>DIAANTEIRO PEUGEOT 207 08/</p> <p><b>19249</b> 10.PG.0367</p>					

<p>BRASILIA 73/77 CROMADO</p> <p><b>06764</b> WOLF-361</p>		<p>BRASILIA 78/82 CROMADO</p> <p><b>04057</b> 5010  <b>08970</b> WOLF-381</p>		<p>CHEVETTE /77 CROMADO</p> <p><b>08952</b> WOLF-1801</p>		<p>CHEVETTE 78/79 CROMADO</p> <p><b>04065</b> 1420  <b>08953</b> WOLF-1831</p>		<p>CHEVETTE 80/82 CROMADO S/FURO</p> <p><b>04066</b> 1820  <b>08955</b> WOLF-1853</p>	
<p>CHEVETTE 80/82 PRETO S/FURO</p> <p><b>04374</b> 1830A  <b>08950</b> WOLF-1855</p>		<p>CHEVETTE 83/86 CROMADO S/FURO</p> <p><b>04068</b> 1570  <b>08959</b> WOLF-1871</p>		<p>CHEVETTE 83/86 PRETO C/FURO</p> <p><b>15229</b> WOLF-1877</p>		<p>CHEVETTE/CHEVY 83/86 PRETO S/FURO</p> <p><b>04151</b> 1870  <b>08917</b> WOLF-1875</p>		<p>CORCEL II 80/84 L PRETO S/FURO</p> <p><b>04156</b> 2360C  <b>08941</b> WOLF-2025</p>	

<p>CORCEL II 80/86 L CROMADO S/FURO</p> <p><b>04153</b> 2250 <b>08939</b> WOLF-2021</p>	<p>CORCEL II 80/86 LDO CROMADO C/FURO</p> <p><b>10508</b> 2260 <b>06773</b> WOLF-2023</p>	<p>CORCEL II 85/86 LDO PRETO C/FURO</p> <p><b>04166</b> 2360A</p>	<p>CORCEL II/PAMPA 85/90 PRETO S/FURO</p> <p><b>04071</b> 2360 <b>08943</b> WOLF-2031</p>	<p>D20 TODAS</p> <p><b>10586</b> B01.01.019 <b>05351</b> CR-10173</p>
<p>DEL REY 81/88 CROMADO</p> <p><b>04160</b> 2380 <b>07247</b> WOLF-2041</p>	<p>DELREY/BELINA/SCALA 81/88 PRETO</p> <p><b>04158</b> 2380A <b>09139</b> WOLF-2045</p>	<p>ESCORT 84/86 PRETO C/FURO</p> <p><b>04376</b> 2410</p>	<p>ESCORT 84/86 PRETO S/FURO</p> <p><b>04164</b> 2420 <b>08948</b> WOLF-2051</p>	<p>FIAT 147 GL CROMADO C/FURO</p> <p><b>08935</b> WOLF-3021</p>
<p>FIAT 147 L</p> <p><b>08929</b> WOLF-3001 CROM <b>08933</b> WOLF-3011 PRETO</p>	<p>FIAT EUROPA 80/84 PRETO</p> <p><b>08931</b> WOLF-3005</p>	<p>FUSCA /70 CROMADO</p>	<p><b>07243</b> WOLF-101M MONTADO <b>08967</b> WOLF-106 GARRA <b>08962</b> WOLF-101 LAMINA <b>08964</b> WOLF-103 TUBO</p>	<p>F1000 /92</p> <p><b>18259</b> B01.02.11</p>
<p>FUSCA 77/86</p> <p><b>04052</b> 5510 CROMADO <b>06759</b> WOLF-491 CROMADO <b>04054</b> 5510P PRETO <b>08972</b> WOLF-491P PRETO</p>	<p>FUSCA MEXICANO CROMADO C/LANTERNA</p> <p><b>02806</b> 5690</p>	<p>GOL 80/86 C/LANTERNA S/FURO</p>	<p><b>04143</b> 5070 CROM <b>08978</b> WOLF-851 CROM <b>04147</b> 5110AS GRAFITE <b>08982</b> WOLF-861 GRAFITE <b>04146</b> 5110S PRETO <b>08980</b> WOLF-859 PRETO</p>	
<p>GOL 80/86 S/LANTERNA S/FURO</p> <p><b>04159</b> 5130 CROMADO <b>04199</b> 5170 GRAFITE <b>08985</b> WOLF-879 GRAFITE <b>04059</b> 5250S PRETO <b>08986</b> WOLF-891 PRETO</p>	<p>KOMBI 77/97 PRETO</p> <p><b>04061</b> 5550 <b>08995</b> WOLF-951</p>	<p>KOMBI 97/06 BRANCO</p> <p><b>04523</b> 5550N <b>08996</b> WOLF-951P</p>	<p>OPALA 75/79 CROMADO</p> <p><b>04232</b> 1070 <b>08919</b> WOLF-1901</p>	
<p>OPALA 80/84</p> <p><b>06770</b> WOLF-1931</p>	<p>OPALA 85/87</p>	<p><b>04229</b> 1900 CROMADO S/FURO <b>08921</b> WOLF-1951 CROMADO S/FURO <b>04230</b> 1980 PRETO C/FURO <b>04231</b> 1980S PRETO S/FURO <b>08923</b> WOLF-1979 PRETO S/FURO</p>	<p>OPALA 88/90</p> <p><b>04227</b> 1100 CINZA DIPLOMATA <b>08925</b> WOLF-1971 CINZA DIPLOMATA <b>04228</b> 1120 PRETO COMODORO <b>08928</b> WOLF-1973 PRETO COMODORO</p>	
<p>PASSAT 77/78 CROMADO</p> <p><b>06766</b> WOLF-531</p>	<p>PASSAT 79/82 PRETO</p> <p><b>09002</b> WOLF-571</p>	<p>PASSAT 79/82 S/LANT CROMADO</p> <p><b>04135</b> 5030 <b>08999</b> WOLF-541</p>	<p>PASSAT 83/86 C/LANTERNA</p> <p><b>04137</b> 5050 CROMADO <b>09000</b> WOLF-545 CROMADO <b>04141</b> 5050A PRETO <b>09001</b> WOLF-573 PRETO</p>	
<p>VARIANT 72/76 CROMADO</p> <p><b>08974</b> WOLF-801</p>	<p>VARIANT I /71 CROMADO</p> <p><b>06762</b> WOLF-201</p>	<p>VARIANT II CROMADO</p> <p><b>08976</b> WOLF-831</p>	<p>FUSCA TEQUILA CROMADO C/LANTERNA</p> <p><b>16407</b> 5590</p>	<p><b>Canezin</b> Distribuidora</p>
<p>PARACHOQUE F250 06/ CROMADO</p> <p><b>19114</b> CAN-19114</p>	<p>BIGODE F250 06/ CROMADO INFERIOR (SPOILER)</p> <p><b>19105</b> CAN-19105</p>	<p>SUPORTE PARACHOQUE F250 06/ DIANT KIT 4 PEÇAS</p> <p><b>19065</b> CAN-19065</p>	<p><b>Canezin</b> Distribuidora</p>	<p><b>Canezin</b> Distribuidora</p>



<p>BELINA SCALA 87/88 PRETO</p>  <p><b>04168</b> 2370D</p>		<p>BRASILIA 73/77 CROMADO</p>  <p><b>06765</b> WOLF-362</p>	<p>BRASILIA 78/82 CROMADO</p>  <p><b>04058</b> 5020 <b>08971</b> WOLF-382</p>	<p>CARAVAN 80/84</p>  <p><b>06772</b> WOLF-1936</p>
<p>CARAVAN 85/87 S/FURO</p>  <p><b>08961</b> WOLF-1956 CROM <b>04306</b> 1970AS PRETO</p>	<p>CARAVAN 88/90 CINZA DIPLOMATA</p>  <p><b>08937</b> WOLF-1976</p>	<p>CARAVAN 88/90 PRETO COMODORO</p>  <p><b>08938</b> WOLF-1978</p>	<p>CHEVETTE 74/79 CROMADO</p>  <p><b>04064</b> 1410 <b>08954</b> WOLF-1802</p>	
<p>CHEVETTE 80/82 S/FURO</p>  <p><b>04067</b> 1840 CROM <b>08956</b> WOLF-1854 CROM <b>04375</b> 1850A PRETO <b>08951</b> WOLF-1856 PRETO</p>	<p>CHEVETTE 83/86 S/FURO</p>  <p><b>04069</b> 1590 CROM <b>08960</b> WOLF-1872 CROM <b>04152</b> 1890 PRETO</p>	<p>CHEVY 500 PRETO</p>  <p><b>06769</b> WOLF-1880</p>		
<p>CORCEL II 80/84 L S/FURO</p>  <p><b>04157</b> 2370C PRETO <b>08942</b> WOLF-2026 PRETO <b>04154</b> 2270 CROM <b>08940</b> WOLF-2022 CROM</p>	<p>CORCEL II 80/86 LDO C/FURO</p>  <p><b>07245</b> WOLF-2024 CROM <b>04167</b> 2370A PRETO</p>	<p>CORCEL II 85/86 L PRETO S/FURO</p>  <p><b>04155</b> 2370 <b>08944</b> WOLF-2032</p>	<p>CORCEL/BELINA GL 85/ PRETO C/2 LANTERNAS</p>  <p><b>08946</b> WOLF-2046</p>	
<p>D20 TODAS</p>  <p><b>18258</b> B01.01.20 <b>05352</b> CR-10172</p>	<p>DEL REY 81/88 CROMADO C/2 LANTERNAS</p>  <p><b>04161</b> 2400 <b>07246</b> WOLF-2042</p>	<p>DEL REY 81/88 PRETO S/FURO</p>  <p><b>08945</b> WOLF-2044P</p>	<p>DEL REY 87 CROMADO C/1 LANTERNA</p>  <p><b>04163</b> 2490 <b>08947</b> WOLF-2048</p>	<p>ESCORT 84/86 PRETO C/FURO</p>  <p><b>04377</b> 2430</p>
<p>ESCORT 84/86 PRETO S/FURO</p>  <p><b>04165</b> 2440 <b>08949</b> WOLF-2052</p>	<p>FIAT 147 GL CROMADO C/FURO</p>  <p><b>08936</b> WOLF-3022</p>	<p>FIAT 147 L</p>  <p><b>08930</b> WOLF-3002 CROM <b>08934</b> WOLF-3012 PRETO</p>	<p>FIAT EUROPA 80/84 PRETO</p>  <p><b>08932</b> WOLF-3006</p>	<p>FUSCA /70 MONTADO CROMADO</p>  <p><b>07244</b> WOLF-102M</p>
<p>FUSCA /70 GARRA CROMADO</p>  <p><b>08967</b> WOLF-106</p>	<p>FUSCA /70 LAMINA CROMADO</p>  <p><b>08963</b> WOLF-102</p>	<p>FUSCA /70 TUBO CROMADO</p>  <p><b>08966</b> WOLF-105 LD <b>08965</b> WOLF-104 LE</p>	<p>FUSCA 77/86</p>  <p><b>04055</b> 5520 CROM <b>06760</b> WOLF-492 CROM <b>04056</b> 5520P PRETO <b>08973</b> WOLF-492P PRETO</p>	
<p>FUSCA TEQUILA CROMADO</p>  <p><b>02807</b> 5700</p>	<p>GOL 80/86 CROMADO C/FURO</p>  <p><b>04595</b> 5100</p>	<p>GOL 80/86 S/FURO</p>  <p><b>04144</b> 5080 CROM <b>08979</b> WOLF-852 CROM <b>04150</b> 5120AS GRAFITE <b>04196</b> 5120S PRETO <b>08981</b> WOLF-860 PRETO</p>	<p>KOMBI 77/97 PRETO</p>  <p><b>08997</b> WOLF-952</p>	
<p>KOMBI 77/97 PRETO C/CATALIZADOR</p>  <p><b>04062</b> 5560</p>	<p>KOMBI 97/06 BRANCO</p>  <p><b>04063</b> 5560N <b>08998</b> WOLF-956</p>	<p>MARAJÓ 80/82 S/FURO</p>  <p><b>08957</b> WOLF-1860 CROM <b>08958</b> WOLF-1864 PRETO</p>	<p>OPALA 75/79 CROMADO</p>  <p><b>04238</b> 1080 <b>08920</b> WOLF-1902</p>	<p>OPALA 80/84 CROMADO</p>  <p><b>06771</b> WOLF-1932</p>

PARACHOQUES

<p>OPALA 85/87 PRETO C/FURO</p> <p><b>04236</b> 1990</p>	<p>OPALA 85/87 S/FURO</p> <p><b>04235</b> 1920 CROM <b>08922</b> WOLF-1952 CROM <b>04237</b> 1990S PRETO <b>08924</b> WOLF-1980 PRETO</p>	<p>OPALA 88/90 CINZA DIPLOMATA</p> <p><b>04233</b> 1110 <b>08926</b> WOLF-1974</p>	<p>OPALA 88/90 PRETO COMODORO</p> <p><b>04234</b> 1130 <b>08927</b> WOLF-1972</p>
<p>PAMPA</p> <p><b>07837</b> CR-21050 LD <b>07838</b> CR-21051 LE</p>	<p>PARATI 83/86 S/FURO</p> <p><b>04198</b> 5230 CROM <b>08984</b> WOLF-876 CROM <b>08990</b> WOLF-884 GRAFITE <b>04372</b> 5210P PRETO <b>08989</b> WOLF-896 PRETO</p>	<p>PASSAT 77/78 CROMADO</p> <p><b>06767</b> WOLF-532</p>	
<p>PASSAT 79/86</p> <p><b>04136</b> 5040 CROM <b>09003</b> WOLF-542 CROM <b>04142</b> 5060A PRETO <b>09004</b> WOLF-572 PRETO</p>	<p>SAVEIRO 83/94 PRETO</p> <p><b>04373</b> MOV-901 C/FURO <b>04139</b> MOV-900 S/FURO</p>	<p>SAVEIRO 83/94 GRAFITE</p> <p><b>08992</b> WOLF-906 S/FURO</p>	
<p>SAVEIRO 95/97</p> <p><b>04060</b> 5270 CINZA <b>08993</b> CR-10248 CINZA <b>08991</b> CR-10249 PRETO <b>08994</b> MOV-781 PRETO</p>	<p>VARIANT 72/76 CROMADO</p> <p><b>08975</b> WOLF-802</p>	<p>VARIANT I /71 CROMADO</p> <p><b>06763</b> WOLF-202</p>	<p>VARIANT II CROMADO</p> <p><b>08977</b> WOLF-832</p>
<p>VOYAGE 84/86 S/FURO</p> <p><b>04197</b> 5140 CROM <b>08983</b> WOLF-872 CROM <b>04200</b> 5180 GRAFITE <b>08987</b> WOLF-880 GRAFITE <b>04201</b> 5180P PRETO <b>08988</b> WOLF-892 PRETO</p>	<p>FUSCA MEXICANO CROMADO</p> <p><b>16410</b> 5600</p>	<p>SPAZIO 83/ PRETO</p> <p><b>04716</b> 3160</p>	

PARACHOQUES



**JUNTA SUPORTE PARACHOQUE**

<p>BRASILIA DIANTEIRO</p> <p><b>09424</b> G-168 LD <b>09423</b> G-167 LE</p>	<p>BRASILIA TRASEIRO</p> <p><b>09422</b> G-166</p>	<p>FUSCA /70</p> <p><b>09426</b> G-170</p>	<p>FUSCA /70 REDONDA</p> <p><b>09431</b> G-126</p>	<p>FUSCA 70/79</p> <p><b>09425</b> G-169</p>
<p>FUSCA 79/</p> <p><b>09428</b> G-172 DIANTEIRO LD <b>09427</b> G-171 DIANTEIRO LE <b>09430</b> G-174 TRASEIRO LD <b>09429</b> G-173 TRASEIRO LE</p>	<p>FUSCA /70 DIANTEIRO</p> <p><b>09433</b> G-125</p>	<p>TRASEIRO</p> <p><b>09432</b> G-124</p>		